

Mounting instructions



AIRCELL®5

SMA-Female (crimp) / item. no.: 7751



1 Push the crimp sleeve over the cable end.
Remove 14 mm of PVC sheath with a knife.



2 Use a side cutter or small scissors to remove 7 mm of the braid.



3 Use a sharp knife to scribe and remove the copper foil.
Bend up the braid a little.



4 Use a sharp knife to cut and remove the dielectric.



5 Push the plug and crimp.



6 Insert the end of the cable thus prepared into the connector housing until it stops.
Push the sleeve onto the connector housing and crimp it.